

Installation Notes for '65-'72 F-Series Bucket Seat Brackets

- It is recommended that the seat brackets be installed on the seat sliders and the seat put into place to determine the location of the inner bracket.
- The bottom feet on the brackets should face inwards toward each other.
- The round spacers go between the seat bracket and the slider. This allows the space necessary for the shoulder on the seat slider bolt.
- The outer seat bracket uses the factory seat bolts.
- The front hole of the inner bracket should be mounted in the center of the u-channel under the floor for support. This can be located by finding the spot welds on the floor.

Use the 5/16" bolt here, with the large washer on top of the bracket and the small washer under the floor with the nylock nut.

- The rear mount will use the 3/8" bolt with the square washer under the floor for support.